



## Delta Series 2, 5 & 7 Vest Measurement Guide

To correctly measure for the Delta Series vests, please use the following procedure:

1. Obtain a flexible tape measure that is in centimetre (cm) format.
2. Ensure you are wearing your usual duty uniform.
3. Standing with your arms raised out to the sides at shoulder level, have a colleague wrap the flexible tape measure around your chest at the largest point and note the measurement.
4. Follow the same procedure to obtain the measurement around your stomach at navel level.
5. Where the tape measure starts overlapping is the measurement required.
6. Repeat the above procedure at least twice to ensure correctness before writing down each of the measurements.
7. Take the highest of the two measurements and cross-reference that size with the below chart to obtain the correct vest size. As an example, if your waist measurement is 98cm and your chest was 102cm, you would use the chest figure of 102cm which would be an XL size.

Waist/Chest Measurement	Vest Size
71 - 80cm	Small
81 - 90cm	Medium
91 - 100cm	Large
101 - 110cm	X-Large
111 - 120cm	2X-Large
121 - 130cm	3X-Large
131 - 140cm	4X-Large
141 - 150cm	5-Large
151 - 160cm	6X-Large

**Remember, you want your armour to fit snugly and contour to your body for maximum concealability, comfort, and protection - this requires accurate measurements.**

*OUR VISION SUPPORTS YOUR MISSION*